



2023 DEMOLITION DERBY RULES

MINI VAN & MINI TRUCK

Engine cannot be bigger than a V6, no V8's . No Durango's or Dakota's

GENERAL RULES

1. Must be 100% stock! No cross breeding of the drive train. It must be the same make as the vehicle (Ex: Chevy to Chevy, Ford to Ford, etc.) and must appear to be the factory engine to the car. Headers are permitted. The engine must be mounted with stock mounts in the stock position. No welding of the mounts is permitted. They must be bolted only.
2. No homemade cross members are permitted. Cross members must be stock and bolted in, not welded.
3. The doors must be chained or wired in no more than 8 places per door. The wire from the bottom of the doors may go around the frame. You may use 5/6" chain or two strands of #9 wire per hole.
4. The trunks must be chained or wired in no more than 8 places. Two of these may go around the bumper and/or the frame. You are not required to have a deck lid and/or tailgate. No welding or adding metal is permitted. The trunk lid must be in the stock location. No tucking, wedging, pre bending, smashing, folding, or anything else you can think of is permitted. No welding washers for holes is permitted.
5. Hoods may be wired or chained in 8 spots. You may use 5/16" chain or two strands of #9 wire per hole. It must be sheet metal to sheet metal only. No welding washers for holes is permitted. There must be a 12" hole in the hood in case of fire. You must remove the hood latch. Hoods must be open for inspection.
6. Any tires are permitted. Doubled tires are permitted. No foam filled tires are permitted. Valve stem protectors are permitted.
7. You may leave the stock gas tank in the stock location, or you may relocate the fuel tank to the rear floor of the car. If this is done you must use a fuel cell or boat tank. If you relocate the fuel tank you have 2 options:
 - a. A back bar is permitted no bigger than 3x3x1/4 and may have 6"x12"x1/4 plates on the ends for mounting, you can have a gas tank holder no bigger than 24" x 24" and it must be 6" away from sheet metal.
 - b. If no back bar is present, you are permitted to have a 24" x 24" x 12" gas tank structure no thicker than 1/4" and it must be bolted to sheet metal only.



8. No stock fuel tanks inside of the car is permitted.
9. The windshield may be left in the car or you can remove the windshield. If removed, you must have a double strand of #9 wire from fire wall to roof.
10. Creasing is not allowed.
11. Stock type springs and shocks are permitted. No solid suspension. Screw in spring risers are permitted. No wire, chains, or any welding on the rear ends or rear spring pockets. Cars must bounce and cars must be stock.
12. You must use the factory rear end for the car you are running.
13. You may weld the spider gears in the rear end to make it posi. No gears are permitted, and you must use stock axles. You are not permitted to change the gear ratio or use aftermarket axles. This will be the driver's responsibility to prove they are not changed.
14. Any car bumper is permitted except for Chrysler pointy bumpers. They must be bolted and welded on in the factory location. You may collapse the shocks and weld all the way around the shock and to the mounting plate to the bumper and there must be a 1/2" gap between the frame and the factory bumper shock plate. You can use 4" x 4" box tubing that is 1/4" thick as a bumper that is no more than 5 feet long with no point. The ends of the bumper must remain open. No metal added to the bumper is permitted. If the vehicle has no shocks, the bumper may be welded directly to the frame with no metal added. On the back side of the bumper where the shock mounts you may use a 1/4" x 6" x 6" piece of flat metal to create a flat mounting surface. DEC bumpers and Adept Products bumpers are permitted. Homemade bumpers must be bolted together, not seam welded.
15. If the car has a wiring harness in front of the core support, you may move it behind the core support.
16. All body bolts must be factory stock. No altering is permitted.
17. You must have a door bar in the driver's door or a 1/8" thick plate can be welded to the inside or outside of the door.
18. The battery can be moved to the passenger side floor or in the seat but must be secured and covered. You can make the battery cables longer to reach the battery.